













LP 5121

Endstufe

R 2010  
R 2020  
R 2022  
R 3010



\* C 503, R 504 nur bei R 2022 enthalten

\*\* R 501 = 1k nur bei R 3010 - Endstufen 1 u. 2 (BASS)

Eigenfertigung

0,25W

0,125W

0,25W

0,125W

0,25W

0,125W


0,25W

0,125W

0,25W

# LP 13145

## LED - Aussteueranzeige



Allen Bauelementen der Lp 13145 ist eine 13 voranzustellen, z.B. C 01 = C 1301

Werte in Klammer [ ] gelten für R 2011 u. R 2021